INSTRUCTIONS



IMPORTANT SAFETY INSTRUCTIONS

WARNING – To guard against injury, basic safety precautions should be observed, including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

DANGER – To avoid possible electric shock, special care should be taken since water is employed in the use of aquarium equipment. For each of the following situations, do not attempt repairs by yourself; return the appliance to an authorized service facility for service or discard the appliance:

- 1) If the appliance shows any sign of abnormal water leakage, immediately unplug it from the power source.
- 2) Carefully examine the appliance after installation. It should not be plugged in if there is water on parts not intended to be wet.
- 3) Do not operate any appliance if it has a damaged cord or plug, or if it is malfunctioning or has been dropped or damaged in any manner.
- 4) To avoid the possibility of the appliance plug or receptacle getting wet, position aquarium stand and tank to one side of a wall-mounted receptacle to prevent water from dripping onto the receptacle or plug. A "drip loop," shown in the figure below, should be arranged by the user for each cord connecting an aquarium appliance to a receptacle. The "drip loop" is that part of the cord below the level of the receptacle, or the connector if an extension cord is used, to prevent water traveling along the cord and coming in contact with the receptacle. If the plug or receptacle does get wet, DON'T unplug the cord. Disconnect the fuse or circuit breaker that supplies power to the appliance. Then, unplug and examine for presence of water in the receptacle.
- 5) Close supervision is necessary when any appliance is used by or near children.
- d) To avoid injury, do not contact moving parts or hot parts such as heaters, reflectors, lamp bulbs, and the like.
- 6) Always unplug an appliance from an outlet when not in use, before putting on or taking off parts, and before cleaning. Never yank cord to pull plug from outlet. Grasp the plug and pull to disconnect.
- 7) Do not use an appliance for other than intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition.
- 8) Do not install or store the appliance where it will be exposed to the weather or to temperatures below freezing.
- 9) Make sure an appliance mounted on a tank is securely installed before operating it.
- 10) Read and observe all the important notices on the appliance.
- 11) If an extension cord is necessary, a cord with a proper rating should be used. A cord rated for less amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.

APPLIANCE POMER SUPPLY CORD DRIP LOOP

Cleaning & Maintenance

This pump is permanently sealed and lubricated so it requires no special maintenance. However, to keep it in peak operating condition and prolong its life, regular cleaning is required to remove dirt, debris or other contaminants. Frequency of cleaning will depend on the operating environment. Check pump frequently to make sure water flow is not impeded or clogged.

To clean pump: Unplug pump from outlet and remove it from the reservoir (do not use the power cord to lift the pump). Gently rotate the outlet housing until the base clears locking tabs. Carefully pull out impeller assembly and rinse it with running water. After cleaning, re-assemble the pump and return it to use. NOTE: Never operate or store pump in freezing conditions.

CONSIGNES DE SÉCURITÉ IMPORTANTES

AVERTISSEMENT – Pour protéger contre les blessures, respecter les consignes de sécurité de base, notamment ce qui suit :

LIRE ET RESPECTER TOUTES LES INSTRUCTIONS DE SÉCURITÉ.

DANGER – Pour écarter les risques de décharge électrique, faire preuve de précautions particulières en raison de la présence d'eau dans l'aquarium. Dans chacune des situations ci-dessous, ne pas tenter de réparer soi-même ; renvoyer l'appareil à un centre de réparation agréé ou le mettre au rebut.

- A. Si l'appareil présente des signes de fuites d'eau anormales, le débrancher immédiatement de la source d'alimentation.
- B. Examiner l'appareil avec soin après son installation. Ne pas le brancher s'il y a de l'eau sur des pièces non destinées à être mouillées.
- C. Ne pas utiliser un appareil s'il a un cordon ou une fiche endommagés, s'il fonctionne mal, s'il est tombé ou s'il a été endommagé d'une quelconque façon.
- D. Pour écarter le risque de mouiller la fiche de l'appareil ou la prise de courant, placer le socle et la cuve de l'aquarium sur le côté par rapport à la prise murale, afin d'éviter que l'eau ne goutte sur la prise ou la fiche. Prévoir une "boucle d'égouttement", illustrée ci-dessous, sur chaque cordon qui raccorde un appareil de l'aquarium à la prise de courant. La "boucle d'égouttement" est la portion de cordon en dessous du niveau de la prise, ou du connecteur si un cordon de rallonge est utilisé, pour empêcher l'eau de s'écouler le long du cordon et de venir au contact de la prise. Si la fiche ou la prise sont mouillées, NE PAS débrancher le cordon. Couper l'électricité au niveau du disjoncteur qui alimente l'appareil. Débrancher ensuite le cordon et voir s'il y a de l'eau dans la prise de courant.
- 3. Une supervision étroite est nécessaire lors de l'utilisation de tout appareil électrique par des enfants ou à leur proximité.
- 4. Pour éviter les blessures, ne pas toucher de pièces en mouvement ni de pièces chaudes telles que radiateurs, réflecteurs, ampoules, etc.
- 5. Toujours débrancher un appareil de la prise de courant lorsqu'il n'est pas utilisé, avant de poser ou d'enlever des pièces et avant de le nettoyer. Ne jamais tirer sur le cordon pour sortir la fiche de la prise. Saisir la fiche et tirer pour débrancher.
- 6. Ne pas utiliser un appareil à d'autres fins que celles prévues. L'emploi d'accessoires non recommandés ni vendus par le fabricant de l'appareil peut produire une situation dangereuse.
- 7. Ne pas installer ni entreposer l'appareil dans un endroit exposé aux intempéries ou à des températures inférieures au gel.
 - 8. S'assurer qu'un appareil monté sur un aquarium est solidement installé avant de le mettre en marche.
 - 9. Lire et respecter toutes les consignes importantes figurant sur l'appareil.
 - 10. Si un cordon de rallonge est nécessaire, utiliser un cordon de capacité suffisante. Un cordon prévu pour des intensités (A) ou des puissances (W) inférieures à celles de l'appareil peut surchauffer. Veiller à disposer le cordon de manière à éviter tout risque de trébuchement ou d'arrachement

SAVE THESE INSTRUCTIONS

CONSERVER CES INSTRUCTIONS

Pump Operation

Make sure all fittings and connections are secure and free of leaks before plugging pump into electrical outlet. If the electrical outlet is lower than the power cord, be sure to set up a "Drip Loop" to make sure that no water runs down the cord and into the electrical outlet.



Thermal Overload Protection: The Model 1200 is equipped with thermal overload protection. If the pump overheats, it will shut itself off and will not restart until a safe operating temperature is reached. The Model 600 is self-protected against the overheating by its own impedance.

Rotating Outlet: For your convenience, pump outlet can be rotated 360° in any direction.

Moveable Suction Cups: Suction cup assembly can be installed in slot on bottom or either side (pump can operate in any position).

EcoPlus® also offers a wide variety of other water and air management products including:

- Water Pumps
- Adjustable Flow Water Pumps
- Water Chillers
- Fans & Blowers
- Fixed Flow & Adjustable Air Pumps
- Air Manifolds
- Air Stones & Diffusers
- Commercial Air Pumps



Limited Warranty

Sunlight Supply,® Inc. One-Year Limited Warranty: EcoPlus® PremioJet™ Pumps are warranted under normal use for one year after purchase date. Any part determined defective in material or workmanship can be returned to an authorized service location designated by Sunlight Supply, shipping prepaid, and will be repaired or replaced at the option of Sunlight Supply.

Limitation of Liability: To the extent allowable under applicable law, Sunlight Supply's liability for consequential and incidental damages is expressly disclaimed. Sunlight Supply's liability in all events is limited to and shall not exceed the purchase price paid.

Warranty Disclaimer: Sunlight Supply provides product information in this literature for the sole purpose of identification, and does state or imply that the products are merchantable or fit for a particular purpose, or that the products will conform to the descriptions.

Product Suitability: Many jurisdictions have codes and regulations governing sales, construction, installation and/or use of products for certain purposes, which may vary from those in neighboring areas. While Sunlight Supply attempts to assure that its products comply with such codes, it cannot guarantee compliance, and cannot be responsible for how the product is installed or used. Before purchase and use of a product, review the product applications, and all applicable national and local codes and regulations, and be sure that the product, installation, and use will comply with them.

Detach and return (or make a copy and return if you wish to save these Instructions).

WARRANTY REGISTRATION FORM

Your EcoPlus® PremioJet™ 600 or 1200 Pump from Sunlight Supply,® Inc. is covered for one (1) full year against manufacturer defects. The warranty information below must be filled out and mailed back with a copy of the purchase receipt for warranty to be in effect. Abuse, neglect, misuse or mis-application of the product will void the warranty.

| EcoPlus® PremioJet™: | <u>600</u> | <u> </u> | | | |
|----------------------|---------------|----------|------------------|---|--|
| | | | / | / | |
| SERIAL NUMBER | | | DATE OF PURCHASE | | |
| NAME | | | | | |
| ADDRESS | | | | | |
| CITY / STATE/ ZIP | | | | | |
| () | | | | | |
| PHONE | EMAIL ADDRESS | | | | |
| Where purchased: | | | | | |
| | STORE NAME | | | | |

Mail this Product Registration Form within 15 days of purchase to:
Sunlight Supply,® Inc., EcoPlus® Warranty Dept.
5408 NE 88th Street - Bldg A, Vancouver WA 98665 USA

THANK YOU FOR YOUR PURCHASE!



EcoPlus® products are exclusively distributed by:

Sunlight Supply,® Inc. / National Garden Wholesale®
5408 NE 88th Street - Bldg A, Vancouver, WA 98665 USA

www.sunlightsupply.com